


Grapadora neumática SIM G97 | Pneumatic stapler SIM G97

Explosionado - Exploded view



Nº	REF.	DESC.
101	9725101	BOLT ASSY
102	9725102	HEX. SOC. HD. SCREW
103	9725103	CAP
104*	9725104	SEAL
105	9725105	COMPRESSION SPRING
106	9725106	O - RING
107	9725107	COLLAR
108	9725108	O - RING
109	9725109	RING
110*	9725110	O - RING
111	9725111	HD. VALVE PISTON
112*	9725112	O - RING
113*	9725113	PACKING
114*	9725114	PISTON RING
115	9725115	O - RING
116*	9725116	DRIVER UNIT
117	9725117	O - RING
118	9725118	CYLINDER
119	9725119	CYLINDER RING
120*	9725120	BUMPER
121	9725121	DRIVER GUIDE
201	9725201	O - RING
202	9725202	TRIGGER VALVE HEAD

Nº	REF.	DESC.
203	9725203	SPRING
204	9725204	PLUNGER
205	7150209	O - RING
205A	9725205A	O - RING
206	9725206	O - RING
207	9725207	PLUNGER CAP
208	9725208	SPRING PIN
209	9725209	TRIGGER
210	3490403	SPRING PIN
211	9725213	SECONDARY TRIGGER
212	2515440	SPRING PIN
213	645208	SPRING
301	9725301	GUN BODY UNIT
302	9725302	GASKET
303	9725303	END CAP
304	9725304	HEX. SOC. HD. BOLT
305	9725305	BRACKET
306	9725306	GUIDE PLATE
307	130304	DUSTY COVER
308	130305	AIR PLUG
309	9725309	O - RING
401	9725401	HEX. SOC. HD. BOLT
402	9725402	SPRING PIN

Nº	REF.	DESC.
403	9725403	DRIVER GUIDE COVER
404	9725404	GASKET
405	9725405	MAGAZINE B
406	9725406	DRIVER GUIDE UNIT
407	9725407	ROD
408	9725408	PUSHER SPRING
409	9725409	PUSHER
410	9725410	PROTECTING HOOD COVER
411	9725411	COUNTER SUNK SCREW
412	7150453	LOCK NUT
413	3490409	HEX. SOC. HD. BOLT
414	9725414	STOPPER
415	9725415	LATCH PIN
416	9725416	SPRING
417	9725417	LATCH
418	9725418	E - RING
419	9725419	SAFETY GUIDE
420	9725420	SAFETY SPRING
421	9725428	SAFETY
422	9725422	RELIEF PLATE
426	9725426	HEX. SOC. HD. BOLT
427	9725427	BOLT ASSY